## microphones. built-in dual noise-cancelling or voice command using control buttons, swipepad interaction, including touch offers multiple modes of M300 Smart Glasses System For optimal ease of use, the **NAVIGATING THE M300** Connector Power -Swipepad -Mounting Rail (Mic, Ambient light, Proximity, Indicator LED) Outer Sensor Window -Power Button -Back Navigation Buttons ☐ Home ☐ Menu Inner Sensor Window (Mic, Proximity) Display-Flash/Flashlight — Recording LED -Camera —

## fig. g

## **USING THE POWER BUTTON**

Short press: when off - power on device, when on - put device to sleep Long press: access power options menu
Press for 10 seconds: force shut down